



liquidGAUGE hidden functions

BHP




↑ Range select, 200/300/400/500
→ Calculation method MAF or Torque
↓ No Action

Coolant /Air Temp




↑ No Action
→ No Action
↓ Units select, degC or degF

Torque




↑ Range select, 200/300/400/500
→ No Action
↓ Units select, ftlb or Nm

Lambda




↑ No Action
→ No Action
↓ Units select, Lambda or AFR

Boost




↑ MAF Boost / Vacuum Estimate
→ No Action
↓ Units select, psi or mbar

Exhaust Temp




↑ Alarm trigger temp up
→ Alarm on/off
↓ Alarm trigger temp down

BHP




↑ Add torque line on/off
→ Halt/Restart display
↓ No Action

Exhaust Temp




↑ No Action
→ No Action
↓ Select CAT temp on/off for Graph Gauge and Multigauge

Actual Boost




↑ Add CMD boost line on/off
→ Halt/Restart display
↓ No Action

Speed RPM




↑ Select SPEED or RPM
→ No Action
↓ Units select, mph or km/h

Cmd Boost




↑ Add Actual boost line on/off
→ Halt/Restart display
↓ No Action

Misfire




↑ No Action
→ No Action
↓ Select cylinder bank 1,2,3,4 or 5,6,7,8 for Missfire and Timing Correction displays

Multigauge



↑ Air Cool N75 Boost
→ No Action
↓ Air Cool Exhaust Oil

Dyno



↑ No Action
→ Once plot complete, boost toggle
↓ No Action